

Quick Start Installation of Marquee W610 player

*NOTE: if this is the first time you have installed a Marquee player, you may want to review the current **Marquee Technical Guide** located in the Support section of marquee.dmx.com.*

Placement - Install the media player:

- a. In a discrete, secure location with minimal access
- b. On a non-switched, grounded power outlet
- c. With convenient access to a broadband internet connection

1. Video/Audio

Video

Connect video cable from the video screen to the appropriate port on the rear of the W610 player. (Monitor must be connected and powered on before powering the player.)

TV Pass-through (optional)

Refer to the instructions in the Marquee W610 Technical Guide.

Audio

HDMI - Player default. If the display is connected to the W610 player via HDMI and has integrated speakers, audio will play through the display.

External amplifier / non HDMI - Connect a male 1/8" (3.5mm) connector cable (not included) to the GREEN audio connector on the rear of the media player. Connect the other end to the audio amplifier or display audio input. Contact DMX Customer Support at 1-800-345-5000 to configure the player's audio.

2. Network

The default network configuration uses a **wired** connection and **DHCP** network addressing. If this is the configuration you're using, connect an Ethernet cable to the player, and connect the other end to a broadband router. If a **static** IP is required, consult the networking section of the Marquee W610 Technical Guide.

Wireless - To configure wireless refer to the instructions in the Marquee W610 Technical Guide.

3. Power

Attach the external power supply to a grounded non-switched outlet. Attach the other end to the player. Your Marquee W610 unit should power on automatically. If not, press the power button on the front faceplate of the media player. The screen will be black for about 25 seconds while the player starts.

4. Call

The startup screen will verify Internet access or identify if there are any connectivity problems. Once the video, power, and network have been configured, call **DMX customer service** to confirm that network connectivity is set up properly. We can be reached at 1-800-345-5000.